

## Frequency Transmitter v5

## **BFRT250**

## DESCRIPTION

The BFRT250 is a loop powered isolating transmitter that accepts a variety of frequency or pulse input signals. Typical inputs include signals from turbine flow meters, NAMUR proximity sensors, or any device producing a DC pulse or pulsing contact. Frequency range is 5Hz up to 5kHz with an amplitude range of 0.1Vp-p up to 50V pulses. NAMUR proximity sensors are directly connected. Standard output is 4 - 20mA with a minimum supply voltage of 6.3V. This enables the BFRT250 to be used in 12V battery supply systems or in automotive applications. Other factory set output configurations are 10-50mA loop powered and 0-10mA, 0-20mA or voltage output in 3-wire connection up to 40Vdc. Higher voltages are permissible with the use of suitable series zener diodes. Double surge protection is standard with all Series 200 loop powered transmitters to prevent failure due to spikes induced by DC switched inductive loads. The input conditioning of the BFRT250 consists of a charge-pump circuit, converting pulse signals produced by a front trigger circuit to an analogue signal. Final calibration is trimmed using the front accessible zero and span 15-turn trim adjustments. A front mounted L.E.D. and a test socket verify module function and assist in calibration checks without disconnection of output wires.


## GENERAL SPECIFICATIONS

Frequency Transmitter v5

GENERAL SPECIFICAT	IUNS	Dref t
Size: Mounting: Housing material: Termination: Protection class: Weight: Protection class: Accuracy error: Linearity error: Long term drift: Temperature effect: Operating temperature: Supply voltage:	23.5W x 71.5H x 109D (mm). Clip for 35mm DIN-Rail. ABS. Top mounted screw terminals. IP40 (IP55 Enclosure Opt). 90 g. IP40. <0.1%. <0.1%. <0.1%. <0.1%. Typically 0.02% of span per °C. -20+70°C. 6.3 - 40V continuous (50V 30 seconds).	
Cupply Voltage.	Supply Voltage $-6.3V$	
Load for 4 -20mA output:	$RLmax = \frac{Supply  volage  0.5  v}{0.02  \text{A}}$	
Load change effect: Response time:	0.1% up to RL max. for 0.5% ripple at 10% of signal $T_{90} = 20$ sec	
Internal offset adjustment: Front zero adjustment: Front span adjustment: Input range: Input level: Excitation for NAMUR sensor Input/output isolation: Electromagnetic compatibility:	2kV r.m.s. except for 3W proximity inputs.	
For input / output combinatic TYPE NO. DESIGNATION ov		
BASI Instrum P.O. Box 53	ent AB Tel: +46 40-880 09 SE-275 06 VOLLSJÖSWEDEN	Fax: +46 40-92 98 77 www.basi.se

BFRT250

OUTPUT OUT SPA



No.DS 50:10E Issue: 4 8/08/11

TYPE NO. DESIGNATION	BFRT250-X X X X
$\begin{array}{c} 1 = 4 - 20 \text{mA.} \\ 2 = 10 - 50 \text{mA} \\ 2 = 3 - 10 \text{mA.} \\ 3 = 0 - 10 \text{mA.} \\ 4 = 0 - 10 \text{mA.} \\ 5 = 0 - 20 \text{mA.} \end{array}$ 2-wire 3 - wire, 0V Ref	<ul> <li>*) 6 = 0 - 1V.</li> <li>*) 7 = 0 - 5V min. supply 10.5Vdc.</li> <li>*) 8 = 0 - 10V min. supply 15.5Vdc.</li> <li>*) 9 = Other (Specify).</li> </ul>
<ul> <li>1 = Sine, sawtooth or pulse, (use '2')</li> <li>2 = Pulse 0.1 - 50Vdc external source</li> <li>3 = 5V pulse; external source (use '2')</li> <li>4 = NAMUR proximity or contact.</li> </ul>	e. *)#6 = 3-wire NPN proximity sensor (not-isolated).
1 = Direct.	*) 2 = Reverse.
Options:	<ul> <li>*) 1 = Output ramp.</li> <li>*) 9 = Other (Specify).</li> </ul>
<ul> <li>r) = Price Extra. # = Use with 3-wire out</li> <li>Front Control Explanation <ol> <li>Test socket - output signal access with reference to terminal (1) loop integrity is maintained when digital multimeter Rin &lt;30 Ω is used.</li> <li>Loop indicator - dim at 4mA, bright at 20mA.</li> <li>SPAN (full scale) adjust 15 turn.</li> </ol> </li> <li>Cutput Connection <ol> <li>Sig +V 0V</li> <li>RL</li> <li>Curre Powered)</li> </ol> </li> <li>Inputs 1 to 5 <ol> <li>NAMUR proximity sensor</li> <li>Pulsing contact input</li> </ol> </li> </ul>	Dutput Ramp Option A external capacitor Ctx used to seconds as shown on the chart below. $ \qquad $
solation due to current drain of proximity sensors.	roximity sensor roximity sensor right to amend, without notice, details contained in this publication. BASI will accept no legal liability for any errors
BASI Instrument AB P.O. Box 53	Tel: +46 40-880 09 Fax: +46 40-92 98 77 SE-275 06 VOLLSJÖSWEDEN www.basi.se